# User's Guide

Concord, Martinez, Pleasant Hill, Walnut Creek

**connect happily** 1-800-4-ASTOUND | astound.net









# **Table of Contents**

Welcome	3
Using Your Remote Control	4
Programming Your Remote Control	5
Audio/Video Cables	6
Cable Television	
Basic Cable	7
Digital Cable	7
Installing Digital Receiver	
TV On Demand	
The Interactive Guide	8
High Definition TV	8
Installing High Definition Television	
Digital Video Recorder	9
Wiring Diagrams	10
Troubleshooting	19
High Speed Internet	
Your Cable Modem	22
Configuring Your Computer	
Astound Email	
Webmail	
High Speed Internet Troubleshooting	29
Home Phone	
Phone Equipment	30
Connecting The Phone	30
Standby Button Reset Button	
Reset Button Battery Back-Up	
Astound Phone Service During a Power Outage	32
MyAstoundPhone.net Portal	
Setting Up Your Voice Mailbox	
Accessing Your Voice Mail	
Voice Mail Features	
Calling Features	
Troubleshooting Tips	

# Welcome To Astound!

#### Thank you for choosing Astound.

Astound is your premier local provider of cable television, high speed internet, and phone services. No matter which package you select we hope you will be impressed with our service – from the breadth of our high definition selection and the speed of our internet access, to the savings of our home phone service and the variety of our exclusive local programming.

Astound prides itself on being number one in hassle-free maintenance, offering FREE in-home service calls and live 24x7 customer care. With Astound there's no expensive equipment to buy or maintain, and no antennas or satellite dishes to worry about.

This User's Guide will help you install and get acquainted with your new service, and help you to reinstall your existing cable or internet connection should you get a new TV or computer.

#### **Ouestions? Contact us!**

With Astound you get prompt, courteous local service. It's just another reason why we are the best choice in TV, internet and phone. Technical support is available 24 hours a day, 7 days a week. If you have questions, please call us at **1-800-4-ASTOUND**, or visit our web site at **astound.net**. In addition to the information in this guide, you can find lots of other useful resources on our website such as:


- Channel Line-ups
- Account Information
- Bill Payment
- Email Support Services

- Webmail
- Technical Support
- and More!



# **Using Your Remote Control**

In the on-screen guide, **yellow** is the highlight color. To navigate the guide, use the arrows on your remote control. The highlight appears on-screen to indicate your current selection. Press ◆ ▶ ▲ ▼ buttons on your remote to move the highlight. Press **OK/SELECT** to confirm your selection. Press **EXIT** on your remote to return to watching TV. For additional settings and information, please visit astound.net.



Note: Your remote may vary from the one shown here; however, the basic functions should remain the same. To see detailed diagrams of most Astound remotes, please visit astound.net

# **Programming Your Remote Control**

For additional settings and information, please visit astound.net.

#### **Auto Search Method**

Your cable remote may be used to control other devices within your entertainment system. You can use the Auto Search Method to find the correct code number for your equipment by following the steps below:

**STEP 1** Turn on the equipment you wish to operate with the remote.

**STEP 2** Press the device button (TV, VCR, DVD, or AUX) to be programmed and the [OK/SELECT] button simultaneously for 3 seconds. The device button LED will turn on.

TIP: The device button LED will turn on for 30 seconds. The next step must be entered while LED is on.

STEP 3 Point the remote toward the equipment and press the [CH+] or [CH-] button one at a time or keep it pressed. The remote will emit a series of power on/off commands. Release the [CH+] or [CH-] button as soon as the equipment turns off.

TIP: You can verify that you selected the correct code by pressing the [POWER] button. The equipment should either turn on or off.

**STEP 4** Press the same device button to store the code. The device button LED will blink twice to confirm that the code has been stored.

It is possible to manually enter a code that directly corresponds to the brand of your device. Refer to the instruction manual that came with your remote, or to view the manual online, please visit astound net.

#### **Programming Volume Control**

By following the steps below, you can program the volume controls (Volume Up and Volume Down) from one device to operate in another device mode. The default volume control settings on the remote control are as follows:

CBL: TV TV: TV VCR: TV

DVD: TV AUX: AUX

If you wish to store the TV volume control in CBL mode, use the following steps.

**STEP 1** Press the [CBL] button and the [OK/SELECT] button simultaneously for 3 seconds. The [CBL] device LED will turn on.

TIP: The device button LED will turn on for 30 seconds. The next step must be entered while LED is on.

STEP 2 Press the [VOL+] button.

**STEP 3** Press the [TV] button. The device LED will blink twice to confirm the programming.

#### To return to the original state:

If you wish to restore the CBL volume control to CBL mode, repeat the above steps by pressing [CBL] in STEP 3.

#### **Programming for Advanced Function**

In the CBL mode, the M [MACRO] button can be programmed to act as a macro or favorite channel button. You can program up to three separate channels that can be accessed with a simple press of the M button.

**STEP 1** Press the [CBL] button to select the CBL mode on your remote.

STEP 2 Press the [M] button and [OK/SELECT] button simultaneously for 3 seconds. The [CBL] device LED will turn on for 30 seconds.

STEP 3 Enter the 3 or 4-digit channel number you want programmed first (for example, 007) using the Number Pad, then press the [STOP] button. Then enter the code for the next channel (for example, 050), then press the [STOP] button. Repeat this process for the third channel. The [CBL] button will blink once for each channel entered.

**STEP 4** Press the [CH+] button to store the functions that were selected. The [CBL] device LED will blink twice to confirm storage of the functions.

#### **Low Battery Warning**

When the batteries are low and need to be replaced, the remote control LED will blink 2 times in sequence whenever a [POWER] button is pressed to turn on equipment.

# **Audio/Video Cables**

### Make the Best Connection!

The cables you use to connect cable to your home entertainment equipment could be as simple as a single line to your television, or as complicated as a multiple component home theater. Your equipment will only work when using the right cables for the job, and you should know how you are hooking up your components. Check the connectors to see what cables you are using:



**Coaxial cable**, or "coax," is the standard cable line that is installed in your home. If you have basic or digital cable, this may be the only kind of cable you need.



Composite RCA consists of three cables that deliver an analog output divided into red and white cables for stereo audio, and a yellow cable for video. They can be used to connect a Digital Cable Terminal (DCT) to a non-HDTV, a VCR or a stereo tuner.



**S-Video** is a sharper alternative to the yellow RCA video cable, but still using the red and white RCA audio cables. It can be used to connect a DCT to a non-HDTV or a VCR.



**Component RCA** consists of five cables that deliver the sharpest analog output, divided into red and white cables for stereo audio, and red, green and blue cables for video. They can be used to connect a DCT to a HDTV or a non-HDTV.



**HDMI** (High Definition Multimedia Interface) is a single cable that delivers a digital audio and video output. It can be used to connect a HD DCT to a HDTV. (You may still wish to use separate audio connections for Surround Sound.)



**DVI** (Digital Video Interface) is a single cable that delivers a digital output. It can be used to connect a HD DCT to a HDTV.



**Coaxial SPDIF** (Sony/Philips Digital InterFace) is a single cable that delivers Dolby Digital 5.1 audio output. It can be used to connect a DCT to a stereo tuner.



**Optical SPDIF** is a single cable that delivers the best available Dolby Digital 5.1 audio output. It can be used to connect a DCT to a stereo tuner.

## **Cable Television**

Astound's cable services include basic cable, digital cable, high definition television and digital video recording. Astound also offers TV On Demand in some areas. Only Astound gives you the local programming you want based on where you live, plus your favorite shows in your time zone.

#### **Basic Cable**

Astound Basic Cable is simple to install. You don't need any additional devices, and you can connect to any cable-ready TV in your home – provided you have activated your Astound cable service. To connect to Astound cable, you simply run a coaxial cable from your wall mounted cable outlet to your cable-ready television set or to your VCR. If you find that your cable outlet is not activated, or you need additional cable outlets installed in your home, please contact us to schedule a professional installation.

#### **Installing Basic Cable**

- The connection from the outlet to your TV, DVD recorder or VCR will always be coaxial cable. If you use a DVD recorder or VCR, you can use a different cable from this device to your TV.
- Check connections to ensure they are threaded correctly and firmly tighten by hand; do not use tools to tighten.
- If you use a DVD recorder or a VCR, you will need to tune your TV to channel 3 or 4 to watch cable. Check with your DVD recorder or VCR user manual for more information
- Since your personal components may vary as well, please refer to your user manual(s) for installation of those components.
- Some channels in Basic Cable may require additional equipment. Check your Channel Line-up card for more information on which channels require equipment.

# **Digital Cable**

Astound digital cable gives you access to up to 300 channels of everything from the local channels you depend on, to hours of entertainment for the kids and so much more!

Astound's digital cable includes digital music too. You can enjoy commercial-free CD-quality music in tons of genres—from classic to modern country to holidays and happenings—digital music offers it all.

You'll also have access to instant pay-per-view events and On Demand movies. You'll love the selection and convenience. Order the latest and most popular movies at the click of your remote!

## **Installing Digital Cable**

- Not all DCTs look alike. The one you receive may vary slightly from the diagram shown in the wiring section beginning on page 10 of this User's Guide.
- Connect your digital cable terminal to your TV, DVD recorder or VCR by referring to the wiring diagrams beginning on page 10. After installation, you may be receiving more channels than you ordered. Within 24 hours, the DCT will automatically reset itself with your programming package.

## **Cable Television**

#### TV On Demand

If TV On Demand is available in your area, it automatically comes with your digital cable receiver. Simply tune to Channel 1 or select "On Demand" from your Interactive Program Guide.

With TV On Demand you choose from a continually updated library of FREE TV, MOVIES, and PREMIUM CHANNELS. Enjoy your favorite shows and movies at your favorite time! Start, pause and rewind at will with a click of your digital cable remote. It's that simple.

- FREE TV Tune in to your favorite TV programs
- MOVIES Rent the latest movies through your digital cable box
- PREMIUM CHANNELS Anytime access to the premium programming you subscribe to

### The Interactive Program Guide

Digital cable comes with an interactive on-screen programming guide. It's intuitive, convenient and easy to use. Search by genre, time or title. Get detailed program information, set reminders and favorites, and use parental controls. For detailed instructions on the Interactive Program Guide, refer to the complete On-Screen Guide quick reference brochure included in your Welcome Kit, or download the information from astound.net.

### **High Definition Television**

High definition television (HDTV) combines extremely high resolution video with Dolby Digital Surround Sound to provide an ultra-sharp viewing experience. Astound provides an enormous amount of HD content, from traditional HD channels to HD On Demand programming available at the push of a button, plus, we're always adding more. Consult your channel line-up for a complete listing of the high-definition channels available in your area.

### Installing High Definition Television

- Not all HD DCTs look the same. The one you receive may vary slightly from the diagrams you'll see in the wiring section of this User's Guide.
- High definition television (HDTV) can be viewed using component RCA, HDMI or DVI connections. Not all HD DCTs have the same connections, and will usually have either HDMI or DVI, not both. If you wish to use the HDMI or DVI connection on your HDTV, but your DCT does not have the appropriate connection, you can call our customer service department or stop by your local office to get a DCT with the connections you want.

## **Cable Television**

### **Digital Video Recorder**

Astound's Digital Video Recorder (DVR) allows you to record and playback your favorite shows and movies with the touch of a button. Astound's dual-tuner DVR lets you watch a live program while recording another, record two programs at the same time, and even watch a previously recorded program while recording others. The DVR DCT is installed in the same manner as a regular DCT, depending on the equipment in your home. Most Astound DVRs are capable of HD service. How you choose to have it connected to your TV or home theater will depend on what services you have from Astound and what your equipment will support.


#### Features:

- Pause, rewind, and re-play broadcasts so you won't miss a moment of your favorite programming
- Watch movies, sporting events and other programs on your schedule
- Easily locate and record shows with the Interactive Program Guide
- Record up to 90 hours of standard definition TV or up to 12 20 hours of HDTV
- Record HDTV shows broadcast in high definition




The diagrams on the following pages will help you understand the various ways in which you can connect a DCT to your television and other home electronic equipment. Not all equipment looks alike, and the DCT you receive may be different.

#### Scientific Atlanta Explorer model 2000




- 1. Smart card slot (Not active)
- Message indicator—indicates a message is waiting when blinking or illuminated
- Display—Displays the channel number and the time of day
- 4. Bypass indicator—Indicates optional bypass feature is on when illuminated
- VOL- and VOL+ —Increases or decreases volume
- 6. Test—For technician use only
- CH- or CH+ —Scrolls up or down through the available channels
- 8. Power—Turns set-top on or off




- 1. Ethernet—Network connection
- USB—High-Speed peripheral device connection (Not active)
- IEEE-1394—Audio and Video device connection (Not active)
- 4. Digital Audio Out—Connect external digital surround-sound receiver
- Data—Connect optional VCR Commander™ module or similar equipment
- S-Video Out—Connect to S-Video input of TV, DVD recorder or VCR
- Video Out—Connect to video input of TV, DVD recorder or VCR

- Audio Out—Connect to L/R audio channels of a stereo receiver or a TV with stereo sound
- Cable Out—Connect to cable input of TV, DVD recorder or VCR
- Cable In—Connect via coax cable to wall outlet
- 11. Bypass—Connect an optional RF Bypass module
- AC Power Input—Connect to an AC electrical outlet
- 13. AC Switched Outlet—Connect the AC power cord from another device, such as a TV


#### Connecting Explorer model(s) 2000-3000 or 2100-3100 to a Stereo TV




# Connecting Explorer model(s) 2000-3000 or 2100-3100 to a Stereo TV and Stereo VCR



# Connecting Explorer model(s) 2000-3000 or 2100-3100 to a Stereo TV with S-Video Cables




#### Scientific Atlanta Explorer model 3250



- Message indicator—indicates a message is waiting when blinking or illuminated
- 2. IR Sensor—Receives the infrared signal from the remote control
- 3. LED Display—Displays the selected channel number and time of day
- 4. Guide—Accesses on-screen services
- Info—Displays a description of the selected program
- Bypass indicator—Indicates optional bypass feature is on when illuminated
- USB—High-Speed peripheral device connection (Not active)

- 8. Exit—Exits menus, the on-screen guide, and program information
- Settings—Provides access to the Settings Menu
- 10. Smart Card Slot (Not active)
- 11. Select—Provides access to your on-screen selection
- 12. CH- or CH+ —Scrolls up or down through the available channels
- VOL- and VOL+ —Increases or decreases volume
- 14. Power—Turns set-top on or off



- 1. IEEE-1394—Audio and Video device connection (Not active)
- Optical Audio Out—Connect an optical cable to an external digital surround-sound receiver or other digital audio device
- 3. DVI—Connect to the DVI input port on your HDTV
- IR Port—Connect the IR Blaster cable to use with the optional VCR Commander™ service
- S-Video Out—Connect to S-Video input of TV, DVD recorder or VCR
- YPbPr Out—Connect to an HDTV via component cables
- Digital Audio Out—Connect an RCA cable to send a digital audio signal to a surround sound receiver or other digital audio device

- Video and Audio Out—Connect via RCA cables to video and audio inputs of TV, DVD recorder or VCR
- Cable Out—Connect to cable input of TV, DVD recorder or VCR
- Audio Out—Connect RCA cables to send analog audio signals to a stereo receiver or HDTV
- 11. Cable In—Connect via coax cable to wall outlet
- 12. Bypass—Connect an optional RF Bypass module
- 13. AC Switched Outlet—Connect the AC power cord from another device, such as a TV
- AC Power Input—Connect to an AC electrical outlet

Scientific Atlanta Explorer 3250

Diagram 1. DHCT Model 3250HD Connected to an HDTV Using Component Video Cables





Diagram 2. DHCT Model 3250HD Connected to an HDTV and Stereo VCR




#### Scientific Atlanta Explorer 8300



- 1. Power—Turns set-top on or off
- 2. Video and Audio Input (Not active)
- 3. List—Displays the list of recorded programs
- 4. Exit—Exits menus, the on-screen guide, and program information
- Info—Displays a description of the selected program
- 6. Guide—Accesses on-screen services
- IR Sensor—Receives the infrared signal from the remote control
- 8. LED Display—Displays the selected chan-

- nel number, time of day, message indicator, power, output resolution, and record light
- VOL- and VOL+ —Increases or decreases volume
- 10. CH- or CH+ —Scrolls up or down through the available channels
- 11. Select—Provides access to your on-screen selection
- 12. Smart Card Slot (Not active)
- USB—High-Speed peripheral device connection (Not active)



- Cable In—Connect via coax cable to wall outlet
- Cable Out—Connect to cable input of TV, DVD recorder or VCR
- YPbPr Out—Connect to an HDTV via component cables
- Digital Audio Out—Connect an RCA cable to send a digital audio signal to a surround sound receiver or other digital audio device
- Secondary Video and Audio Out—Connect to either a DVD recorder or VCR for archiving saved content or to another set of inputs (composite) on your HDTV
- Audio Out—Connect RCA cables to send analog audio signals to a stereo receiver or HDTV

- Optical Audio Out—Connect an optical cable to an external digital surround-sound receiver or other digital audio device
- 8. S-Video Out—Connect to S-Video input of TV, DVD recorder or VCR
- 9. HDMI—Connect the HDTV HDMI™ connector to the HDMI port
- 10. IR Port (Reserved for future use)
- 11. SATA Connector (Not active)
- IEEE-1394—Audio and Video device connection (Not active)
- 13. AC Switched Outlet—Connect the AC power cord from another device, such as a TV
- 14. AC Power Input—Connect to an AC electrical outlet

Diagram 1. Connecting your DVR to your TV and VCR








Diagram 2. Connecting your DVR to your Stereo TV and Stereo VCR




#### Scientific Atlanta Explorer 8000



- 1. Power—Turns set-top on or off
- Message Indicator—Indicates a message is waiting when blinking or illuminated
- 3. LED Display—Displays the selected channel number and time of day
- 4. IR Sensor—Receives the infrared signal from the remote control
- Recording Indicator—Indicates the DVR feature is active when illuminated
- VOL- and VOL+ —Increases or decreases volume
- Select—Provides access to your on-screen selection

- 8. USB—High-Speed peripheral device connection (Not active)
- 9. CH- or CH+ —Scrolls up or down through the available channels
- 10. Guide—Accesses on-screen services
- 11. Info—Displays a description of the selected program
- 12. Smart Card Slot (Not active)
- 13. Exit—Exits menus, the on-screen guide, and program information
- 14. List—Displays the list of recorded program



- IEEE-1394—Audio and Video device connection (Not active)
- S-Video Out—Connect to S-Video input of TV, DVD recorder or VCR
- IR Port—Connects to optional VCR Commander™ service
- Digital Audio Out—Connect an RCA cable to send a digital audio signal to a surround sound receiver or other digital audio device
- TV Out—Connects composite cables to the video and L/R audio inputs of a standarddefinition TV
- 6. VCR Out—Connects to video and L/R audio

- inputs of a VCR
- Cable Out—Connect to cable input of TV, DVD recorder or VCR
- 8. Auxiliary Input (Not active)
- Serial Number—Located in the lower leftcorner of the bar code
- Cable In—Connect via coax cable to wall outlet
- 11. AC Switched Outlet—Connect the AC power cord from another device, such as a TV
- AC Power Input—Connect to an AC electrical outlet

Scientific Atlanta Explorer 8000 or 8300 HD/DVR

Diagram 1. Connecting the 8000 or 8300 HD-DVR using component connection





Diagram 2. Connecting the 8000 or 8300 HD-DVR using DVI Connection



Note: When connecting the HDMI connector to the HDTV's DVI connector, you need an HDMI-to-DVI adaptor, and you need a separate audio connection.

# **Troubleshooting**

#### **Digital Cable Troubleshooting**

If you subscribe to Digital Cable you can connect any number of television sets in your home for service, but you will need an additional DCT or CableCard to receive digital channels for each television you connect. You do not need extra equipment to receive Basic Cable on additional television sets.

- If you have a DVD recorder or a VCR, be sure to connect it between the DCT and the TV. Make sure to tune your TV, DVD recorder or VCR to channel 3 or 4 and use the digital remote to watch cable.
- If you have a TV with multiple inputs for coaxial, S-Video and RCA cables, make sure your TV is set to the correct input.
- Your cable remote should be programmed to control your television, as well. If it is not, refer to the instructions on page 4 of this manual to program it. Once it is programmed successfully, control your TV volume using the cable remote.
- If you have picture but no sound, check to see if the DCT volume has been reset, or if the TV is muted. If you have no sound and are using a stereo tuner, check the cable connections and settings for the tuner.
- If you are not receiving all of your channels, or if the on-screen guide is showing "One Moment Please" for more than a few minutes, power-cycle the DCT by unplugging the power for one minute. Your programming package should reload within a few minutes, but the on-screen guide and menu, or the PPV and TV On Demand programming, can each take up to one hour to reload.
- If the DCT indicates it is downloading programming with "DL" displayed on the front panel, this process may take up to 30 minutes. If you power-cycle the DCT during this time, the download will start over. If the display shows "DL" for more than 30 minutes, you should call our technical support department. If the DCT shows another error code on the front panel, please call our technical support department.
- If you have a TV with a CableCard and you lose some of the programming, unplug the CableCard and power-cycle the TV by unplugging the power for one minute. Securely plug the CableCard back into the TV and then restore power to the set.

#### **Digital Cable FAQs**

#### Q: What's the difference between Astound's digital cable and satellite?

A: For starters, you won't lose signal like you can with a dish in wind and rain. With Astound's digital service you get local programming that's not available on a dish. In most cases, you automatically get TV On Demand – a technology ONLY available on cable. You don't have to worry about buying a receiver or installing an ugly satellite dish on your roof. And there are no hidden up-front costs or service contracts. Plus, most in-home service is FREE!

#### Q: How many television sets can I connect to Astound's digital cable?

A: If you subscribe to Astound's digital cable you can connect any number of television sets in your home to the service, but you will need an additional digital cable receiver to receive the digital channels for each television you connect. You do not need additional equipment to receive Basic Cable on additional outlets.

#### Q: Do I have to pay extra for access to TV On Demand programming?

A: No, if you order digital cable, you receive access to TV On Demand programming if it's available in your area. TV On Demand includes three types of programming: Pay-Per-View movies and events, Free TV On Demand and Premium On Demand, which automatically comes with your premium channel subscription such as Starz!, HBO, and Showtime/TMC.

# **Troubleshooting**

#### **High Definition Television Troubleshooting**

- If you do not have a picture on your HDTV, turn off all equipment and check your connections. Some connectors such as HDMI can slip loose of the equipment, in which case you'll want all equipment off when reconnecting.
- If the picture is not displaying correctly with a digital connection, you may need to switch to an analog connection to troubleshoot your settings.
- The DCT output settings must match your HDTV input settings. To check the DCT output settings, turn the DCT off and hold down the Info and Guide buttons on the front panel at the same time.
   To check your HDTV input settings, check the manual or contact the support department for your HDTV manufacturer.
- Many home theater systems use automatic switching, allowing you to connect multiple devices to the receiver, and connect a single cable from the receiver to the television.
- If you use a receiver between the DCT and your HDTV and encounter any problems, try bypassing the receiver. Some receivers do not relay all digital copy protection signals, which prevents the picture from being displayed.
- If you have no sound and are using a stereo tuner, check the connections to and settings for the tuner. If you have no sound only on HD channels, your system may not be compatible with the multi-channel audio formats available with HDMI and SPDIF. If this is the case, set the digital audio setting for your HDTV or stereo tuner to PCM. This will convert the digital signal to an analog form the equipment can use.
- If any additional equipment in your home theater is not working correctly, you will want to refer to the user manual(s) for that equipment, or contact the support department for that equipment. The settings on audio/video equipment vary greatly from one manufacturer to another, and Astound technical support is not trained to troubleshoot third-party equipment.

#### **HDTV FAOs**

#### Q. What do I need in order to receive HDTV?

A. In order to receive HDTV, you must have a HD television and one of the following: HD cable receiver, HD-DVR receiver, or HD cable card from Astound. Your high definition television must have an HDMI, YPbPr component or DVI input and must support either 720p or 1080i HD format. Refer to your television's user manual to determine if your HDTV set supports either of these formats.

#### Q. I already have a high definition television. Do I still need an HD receiver?

A. Yes. To receive Astound HDTV service, you must have a HD television and one of the following: HD cable receiver, HD-DVR receiver, or HD cable card from Astound that enables you to watch HDTV programming.

#### Q. What is the difference between HDTV and digital cable?

A. Digital cable is a type of television signal. HDTV is the highest quality in digital signals, offering better resolution and sound than a standard digital signal. Digital cable can be watched on your existing standard television if you have a digital cable box. But HDTV requires both a high definition television capable of displaying 720p, 480i and/or 1080i and a high definition cable box.

#### Q. How will high definition service look on my regular analog television?

A. HD signals will not display on regular analog TV sets, since those TVs don't include the advanced technology required to display HD signals.

# **Troubleshooting**

#### **Digital Video Recorder Troubleshooting**



#### **DVR Operation Safety**

A DVR requires plenty of open space for ventilation. It is preferable to have at least 2" of clearance above the DVR, and 1" of clearance to the left and right sides of the DVR. Do not place the DVR in a closed cabinet.

- If the fan in the DVR is making an excessive amount of noise, check the ventilation and feel how
  much heat is being generated around it. The DVR may need to be placed in a different position that
  allows more air flow.
- The troubleshooting tips for Digital Cable (p. 20) and HDTV (p. 21) also apply to possible issues with a DVR. However, if it is necessary to power-cycle the equipment, you will want to leave the DVR unplugged for two minutes, or until it is no longer warm to the touch.
- After a power-cycle of the DVR, it may take up to one hour for the menu features to be restored.
   However, the LIST button on the remote should work to access recorded programs, once TV reception has returned.
- Many DVRs are manufactured with data connections, such as USB, Ethernet, IEEE 1394 (firewire) and SATA, for future functionality. These connections are not active at this time.

#### **DVR FAQs**

#### Q: How can I get digital video recording?

A: For an additional monthly fee, Astound will provide you with a digital video recorder.

#### Q: Do I have to purchase a DVR?

A: Unlike other providers, you don't have to purchase any expensive equipment, or worry about maintenance or replacement should your DVR malfunction. Astound maintains all DVRs and will repair or replace yours, free of charge, should it need service.

#### Q: Can I use my VCR/DVD player with a DVR?


A: Yes. The DVR works with all home entertainment equipment including VCRs, DVD players, and surround sound systems, but may require custom configuration beyond the scope of this document. For more information, refer to the user manuals specific to your entertainment system components.

This guide will help you become acquainted with Astound's internet service and provide step-by-step instructions on how to install or reinstall your cable modem. It also provides instructions on how to create your **astound.net** email account, and configure it to work with email software on your computer.

Any standard cable modem will work with Astound service. These instructions reference the Motorola Surfboard modem, but can be used with any model. If you have specific questions about your model of cable modem, please check the user's manual, many of which are available on astound.net.

#### Your Cable Modem

First, connect the coaxial cable to the wall outlet or cable splitter, and to the CABLE port on the modem. Thread and tighten the connections by hand; do not use tools to tighten. Then attach the power cord to the cable modem and plug the cord into an electrical outlet. Check the modem lights to verify it is able to connect to the internet.



1 Standby

transmitted or received when the Standby light is on. All other front panel lights turn off until you press the Standby button again. Flashing: Startup diagnostics in progress On: The cable modem is powered on. Flashing: Scanning for a receive (downstream) channel connection On: The downstream channel is connected Flashing: Scanning for a send (upstream) channel connection On: The upstream channel is connected Flashing: Scanning for a network connection On: The startup process is complete Flashing: Transmitting or receiving data On: A device, such as a computer or hub, is connected to the USB or Ethernet connectors on the back panel 7 Standby This light does not flash

Press to suspend your Internet connection. No data is

On: Internet service is blocked because the Standby button was pressed. If this light is on, all other lights are off.

During normal operation, the Power, Receive, Send, and Online lights are on and the PC/Activity light flashes when the cable modem is transferring data.

Most cable modems other than the Motorola Surfboard indicate online status with a single cable light. If the cable light is flashing, the modem is acquiring a connection to the internet; if it is solid, the modem is online.

If the modem is not able to connect to the internet, then the cable wall outlet may need to be adjusted. Please call our support department to schedule a time when an Astound technician can perform this work. If you are using a cable splitter to connect both the modem and your TV, it will affect the signal received by the modem. You can bypass the splitter and connect the modem directly to the wall outlet, to see if the modem can connect to the internet without using the splitter.

Once the modem is connected to the internet, connect the cable modem to your computer using either an Ethernet cable, or USB cable.



#### Ethernet or USB?

Ethernet is the preferred method for connecting your computer to your cable modem. Most newer computers have a built-in Ethernet port. It can be found on the back of your computer and looks similar to a telephone jack, but somewhat larger.







*		
1	1 Ethernet	The Ethernet port provides a connection to Ethernet-equipped computers using a cable terminated with an RJ-45 connector.
3	2 USB	The USB port provides a connection to USB-equipped computers (Requires specific software)
	3 Cable	The Cable port provides a connection to the coaxial cable (coax) outlet.
4	4 +12VDC	This connector provides power to the cable modem.

### **Configuring Your Computer**

Once the cable modem is online and connected to your computer, it is necessary to set up your computer to access the internet through the modem. If you do not have an Ethernet port and are connecting with USB, it is necessary to first install the proper USB drivers. Contact an Astound service technician at 1-800-4-ASTOUND if you need assistance connecting via USB.

### **Provisioning Your Operating System Software**

With most cable modems, the "cable" and "status" light will blink until connected then stay solid. The "PC" light should blink when connected, and the "data" light will blink when actively used. If the lights are not lit, please follow the appropriate steps for the software you are using. Once the proper cables have been connected, and the "cable" and "status" indicator lights are solid, you are ready to connect to the Internet. Locate your computer's operating system and follow the instructions how to provision it for internet access.

In all cases you will need to make the following settings:

- 1. Set connection type to Ethernet (or USB if this is the case with your computer)
- 2. Set internet protocol to TCP/IP
- 3. Set IP and DNS addresses to "Obtain Automatically"

If you do not see your software listed on the following pages and need assistance, please call technical support and we will be happy to assist you. Please note that Astound only supports Windows 7, Vista, XP, or 2000, or Mac OS 8.5-9.2 or OSX and above.

#### Internet FAQs

#### Q. How does Astound's cable modem access differ from DSL?

A. DSL stands for "Digital Subscriber Line" and is the technology used by most phone companies to provide Internet access. In order to receive quality DSL service you must live close to the telephone company's Central Office (CO). If you live too far from the CO you may experience slow service or not be able to receive service at all. Unlike DSL, Astound's network provides reliable high speed service in a variety of speeds and prices, no matter where you live on our network.

#### Q. Do I need a user ID or password to access the Internet?

A. You do not need a password to access the Internet—once your cable modem is connected and configured properly you have an always-on, direct connection to the web. You will need a login name and password to access your email account.

#### Q. How do I set up my Astound email account?

A. You can call Astound technical support to set up your email account and have your password set, or you can create an email address online within Astound's Internet Account Manager at astound.net/iam. Once your email account is active, you can use your login and password to access your account and configure email client software (such as Outlook).


#### **Configuring Windows 7**

- Click the "Start" button and select "Control Panel".
- Click on the "Network and Internet" icon.
- Click on the "Network and Sharing Center" icon.
- Click on the "Local Area Connection" link.
- On the "Local Area Connection Status" window that appears, click the "Properties" button.
- In the list of network components, select "Internet Protocol Version 4 (TCP/Ipv4)" and click the "Properties" button.
- Select "Obtain an IP address automatically" and "Obtain DNS server address automatically".
- Click the "OK" button.
- Click the "Close" button on Local Area Connection Properties.
- Click the "Close" button on Local Area Connection Status.



#### **Configuring Windows Vista**

- Click the "Start" button and select "Control Panel".
- Double-click "Network and Sharing Center".
- Next to "Local Area Connection", click "View Status".
- In "Local Area Connection Status" click the "Properties" button.
- In the list of network components, select "Internet Protocol Version 4 (TCP/Ipv4)" and click the "Properties" button.
- Select "Obtain an IP address automatically" and "Obtain DNS server address automatically".
- · Click the "OK" button.
- Click the "Close" button on Local Area Connection Properties.
- Click the "Close" button on Local Area Connection Status.




#### **Configuring Windows XP**

- Click the "Start" button and select "Control Panel".
- If the Control Panel says "Pick a category" click "Switch to Classic View".
- Double-click "Network Connections"
- Right-click "Local Area Connection", select "Properties" and make sure you are on the "General" tab.
- In the list of "This connection uses the following items:" select "Internet Protocol (TCP/ IP)" and click the "Properties" button.
- Select "Obtain an IP address automatically" and "Obtain DNS server address automatically", then click the "OK" button.
- Close the "Local Area Connection Properties" by clicking the "OK" button.



### **Configuring Windows 2000**

- · Click the "Start" button and select "Control Panel".
- Double-click the "Network and Dial-Up Connections" icon.



- · Double-click "Local Area Connection".
- Select either "USB" or "Ethernet Adapter" (NIC), as appropriate.
- · Double-click on "Internet Protocol".
- On the Properties screen, select "Obtain an IP address automatically" and "Obtain DNS server address automatically".
- Click the "OK" button.
- Close the "Local Area Connection" window by clicking the "OK" button.
- · Close the "Network and Dial-Up Connections" control panel.

#### Configuring Mac OSX, 10.1.5 or later

- Click on the System Preferences icon in the System Dock, or click on the Apple menu and select "System Preferences".
- In the System Preferences window, click on the "Network" icon.
- In the Network Preferences window, click on the "Locations" menu and select "Automatic".
- Click on the "Show" menu and select "Built-in Ethernet".
- Click on the "Configure" menu and select "Using DHCP".
- Make sure all other fields are black and click the "Apply Now" button.
- · Close the Network Preferences window.





### Configuring Mac OS 8.5 - 9.2

- Click on the Apple menu, move the mouse over "Control Panel", and select "TCP/IP"
- On the TCP/IP control panel, click on the "Connect via:" menu and select "Ethernet".
- Click on the "Configure:" menu and select "Using DHCP Server".
- · Click on the "File" menu and select "Quit".
- On the warning dialog box that asks, "Save the changes to the current configuration?" click the "Save" button.



#### **Astound Email**

While you can use any email provider you choose with Astound High Speed Internet, up to ten **astound. net** or **myastound.net** email addresses are included with your service. Each email address can store up to 50 MB of messages on Astound's mail server. You can create an email address by going to **astound. net/iam.** Alternately, you can call our technical support department, and our staff can create one or more email addresses for you, and help you configure your computer.

Once your email address is created, you can configure email client software on your computer to access it, such as Windows Mail, Outlook Express or Mac Mail. Any email software you use will need the following information to send and receive email for your astound.net or myastound.net address:

**Display Name:** Your full name as you want it to appear in emails

Email Address: Your full email address, eg. johndoe@astound.net or

johndoe@myastound.net

**Incoming Mail Server:** mail.ca.astound.net for astound.net email addresses

mail.myastound.net for myastound.net email addresses

**Outgoing Mail Server:** smtp.ca.astound.net for astound.net email addresses

mail.myastound.net for myastound.net email addresses

Account Name: The first part of your address, eg. johndoe

Password: The password you set up when creating the address

For complete instructions on how to set up the most common email client programs, visit **astound.net**, click on the "Support" menu and select "Internet Help".



### **Using Another Email Provider**

If you wish to use another email service rather than the email that comes free with your Astound internet, you will need to use the account settings for incoming mail from that provider. However, you will need to use mail.ca.astound.net as your outgoing mail server – all other settings should be provided by your email service provider.

### Webmail

Any time you are away from home and wish to check for new mail, or if you have not set up an email client program on your computer, you also have the option of accessing your email through our Webmail program. Webmail is available by going to **astound.net**, and selecting "Webmail" or go to **astound.net**/ webmail.

When you login, your Login Name is the first part of your email address, eg. if your email address is *johndoe@astound.net*, your Login Name is *johndoe*. If you are connecting from a computer using some form of security, you may need to select one or both of the check-mark boxes below the Login Name and Password.

### **High Speed Internet Troubleshooting**

If you are unable to connect to the internet, first check your cable modem to see if it is online (see diagram, p. 22). If it is not online, power-cycle the modem by unplugging the power for 30 seconds. If the modem cannot establish the connection to the internet within a few minutes after the power-cycle, please call our technical support department for more help. If you are using a cable splitter to connect both the modem and your TV, you can bypass the splitter and connect the modem directly to the wall outlet to see if the modem can connect to the internet without using the splitter.

If you have created a network in your home using a router, you will want to power-cycle both pieces of equipment:

- 1. Unplug power to both the modem and the router.
- 2. After 30 seconds without power, restore power to the modem.
- 3. Once the modem is online, restore power to the router.
- 4. Once the lights on the router indicate a connection, repair the internet connection on each computer. This may require restarting the computer.

If the cable modem indicates a connection to the internet, but your computer cannot connect through a router, you will need to bypass the router and plug one computer directly into the modem:

- 1. Unplug the power to both the modem and the router.
- 2. Use a single Ethernet cable to connect the modem and one computer.
- 3. After 30 seconds without power, restore power to the modem.
- 4. Once the modem is online, repair the internet connection on the computer. This may require restarting the computer.

If you are able to connect to the internet using a computer plugged directly into the modem, but cannot connect using your router, then your Astound internet service is working. You will want to contact the support department for the manufacturer of your router. If you received the router from Astound as part of our Wireless Home Networking service, please contact our technical support department for problems connecting with the router.

If you are able to connect to the internet, but have another issue with your internet service, please check our website for a number of troubleshooting guides and tips. Go to astound.net, and select "Support".




#### **Internet Security**

Any time your computer is connected to the internet, no matter what kind of connection is being used – through cable modem, DSL or dial-up – there is some risk of your privacy being compromised. There are a number of things you can do to minimize your risk, such as installing firewall and virus protection software. You can also turn off "file sharing" and "network sharing" settings on your computer.

Astound Phone works just like other home phone services you may be used to, though it does require some equipment that you may not be familiar with. An Astound Technician will connect a small device called a Multimedia Terminal Adaptor (MTA) between your cable line and the existing phone jacks in your home to enable the service. If you have high-speed internet service from Astound, the MTA may also act as your internet cable modem

### **Phone Equipment**

**Note:** Not all Multimedia Terminal Adapters (MTAs) look alike. The one you receive may vary slightly from the diagram below.



- Power Light: indicates whether AC power is available to the unit
- DS (Downstream): indicates downstream connectivity
- 3. US (Upstream): indicates upstream connectivity
- 4. Online: indicates internet data transmission status
- Link: indicates Ethernet or USB connectivity between the MTA and computer
- **6. Telephone Line 1:** indicates status of line 1
- Telephone Line 2: indicates status of line 2
- 8. Battery: indicates status of the battery in the MTA


# Connecting The Phone Standby Button

Some MTAs have a Standby button on the front of the unit. Pressing the Standby button will either suspend or activate your computers connection to the Internet.

- Online Mode Modem is online indicated by an illuminated Online light on the Telephony Modem.
- Standby Mode Modem is offline and in standby indicated by a blinking Online light.

The Standby button does not affect telephone service; telephony service will work regardless of the status of your computer's connection to the internet.





#### **Reset Button**

Using a paper clip to push the Reset button on the back of the Telephony Modem will reset the modem.

- Straighten a paper clip and press into the reset hole in the back of the MTA.
- Hold down this button until the lights on the front of the MTA turn off and then release.



### **Operation Safety**

Connecting the Telephony Modem (MTA) to your existing telephone wiring should be performed by a professional installer. Failure to do so may result in electrical shock, loss of phone service, loss of 911/E911 service and/or permanent damage to the Telephony Modem.

#### **Battery Back-up**

Astound's telephony modems come equipped with battery back-up already built-in. The battery will maintain your phone service during a power outage. How long the battery will work depends on your model of telephony modem and how well the battery retains a charge.

The estimated life of our telephony modem batteries is 6 to 10 years. If you have any concerns about the age or functionality of your modem battery, we offer free battery checks, up to once a year.

### **Astound Phone Service During a Power Outage**

Astound phone service relies on a telephony modem to work, and that modem requires power to operate. If you lose power in your home, then your Astound phone service requires a backup power source to function.

The built-in modem battery back-up will continue to power your phone service until the battery runs out or external power to your house is restored. If you have your own back-up power supply, such as a generator, then you can use this power source to run your telephony modem during an outage.

We also recommend having at least one telephone receiver in your home that does not require an external power source (does not plug into an electrical outlet), or make sure you have a battery back-up, or secondary power source, for your telephone receiver as well.

Astound phone, like all Astound services, also requires that our facilities maintain power. To that end, all of our key facilities have automatic back-up generators, and we have our own back-up power supplies at most other levels throughout our systems, as well as contingency plans in place to minimize the likelihood of an outage. In the unlikely event that the Astound facility that supplies service to your home loses power, then your phone service will not work, even if you have power at your location.

If you have an emergency alert system that uses your landline phone, such as Life Alert, that system will not work if your Astound phone service is not working. We encourage you to have a charged battery back-up or another secondary power source available to maintain your phone service in the case of a power outage to your home— as well as alternative methods of communication, such as a Go Phone for emergency situations.



# 911/E911 Emergency Information

If you attempt to install or use the Astound equipment or VoIP services at another location, the VoIP services, including but not limited to 911/E911, may fail to function or may function improperly.

Astound phone service is electrically powered and that service, including the ability to access 911 services, security and medical monitoring services, may not operate in the event of an area power outage or if the cable connection is disrupted or not operating.

Included with your equipment are advisory warning stickers that provide information regarding the limitations of 911/E911 service with VoIP services. Please place these stickers on or near the equipment used with Astound Phoneservices.

# MyAstoundPhone.net Portal

- · Check voice mail messages online at http://www.myastoundphone.net.
- · Set up your voicemail preferences.
- Manage your Home Phone features such as voicemail/call forwarding, call screening and contact list.
- Get e-mail alerts when you receive voicemails.
- Detailed instructions for using the Home Phone Portal can be found at http://www.astound.net/myastoundphone



Go to: http://www.myastoundphone.net Use your voicemail PIN to log into the Phone Portal.

# **Setting Up Your Voice Mailbox**

- To set up your voice mailbox for the first time you must dial (\*9) or your telephone number from your Home Phone.
- You will be prompted to create a PIN of four to twenty digits.
- Record a name announcement.
- Record a personal greeting or select one of the standard greeting options.
- Prompts will allow you to correct and re-record announcements in case you are not satisfied with what you have recorded.

# **Accessing Your Voice Mail**

- From home, dial (\*9) or your telephone number
- Away from home, dial your telephone number and press (\*) during the greeting
- · Online, go to http://www.myastoundphone.net

#### Voice Mail Features

- Incoming calls will be forwarded to voicemail after 24 seconds /4 rings by default. You can change this setting at MyAstoundPhone.net
- Each message is time and date stamped
- Messages can be up to 2 minutes in length
- You can store up to 30 messages or 60 minutes worth of messages
- Messages can be saved for up to 30 days. To save messages, press (2)
- To fast-forward 5 seconds during message playback, press (99)
- To rewind 5 seconds during message playback, press (77)
- Press (#) to keep the current message and skip to the next message
- To delete a message, press (3)
- To reply to a message, press (4)
- Press (0) for helpful hints

#### Changing Your Greeting, Name and PIN

- Access your voice mail by dialing (\* 9) or your phone number, followed by your PIN
- Press (3) to change your greeting and follow the prompts
- To change your name, press (3) for the greetings menu, then press (3) to change your name and follow the prompts
- To change your PIN, press (4) for mailbox settings, then press (3) for security options and follow the prompts



### **Message Indicator**

If you have a new voicemail, you will notice a "staggered" dial tone when you pick up the line. This will continue until you have called and checked your voicemail.

### **Calling Features**

The following features are included with Unlimited Phone or can be added to our other phone plans for an additional monthly charge.

Call Waiting – A tone will announce an incoming call when you are already on the phone. This
feature comes automatically activated when included with or added to your Astound Phone service.

**Cancel Call Waiting (\*70)** – Turn off call waiting on a per call basis. Enter the code before making the call.

- Caller ID & Call Waiting Caller ID View caller information for incoming calls. These features come automatically activated when included with or added to your Astound Phone service.
- Caller ID Block (\*67) Block your Caller ID information from displaying on outbound calls on a per call basis. Enter the code before making the call.
- **Disable Caller ID Privacy (\*82)** Turn off Caller ID Privacy on a per call basis. Enter the code before making the call.

**Note:** This feature is used if you have Caller ID Privacy set as a permanent feature on your Astound Phone. You will receive a message when calling an individual who does not accept anonymous calls. Simply hang up, dial \*82 and try again.

- **Disable Inbound Caller ID (\*85)** Turns off any caller ID information when receiving a call. \*65 will re-enable the feature if it has been disabled using \*85. Please note: \*65 will only enable from a disabled state. It cannot activate the caller ID feature.
- Repeat Dial (\*66) If you receive a busy signal when making a call, you can hang up, pick up the receiver again and enter the code. The system will continue to call the last number you dialed for up to 30 minutes. Once that line is free, your phone will ring with a distinctive ring. You may continue to make and receive phone calls as normal while this feature is activated.

Cancel Repeat Dial (\*86) – Disable repeat dial before the 30 minute time frame is over.

• Return Call (\*69) – Return the call of the last person who called you. Like Repeat Dial, if the line is busy it will continue to redial the number for up to 30 minutes.

**Note:** If the caller is calling you from a cellular phone, this feature will tell you the number of the last caller but you will receive a busy signal if you attempt to dial them back through the Return Call menu. Simply hang up and dial the number directly.

Cancel Return Dial (\*86) – Disable return call before the 30 minute time frame is over.

Call Forward (\*72) – Forward incoming calls to another telephone number. If you forward calls
to a long distance number, long distance charges may apply depending on your Astound Phone
package. To activate Call Forwarding, press \*72, wait for the confirming beeps, and then enter the
phone number you would like calls forwarded to. You will immediately get a courtesy call at the
phone number where calls will be forwarded. Answer the courtesy call to activate Call Forwarding. If
you cannot answer the courtesy call, you must dial \*72 again from your Astound Phone and wait for
the confirmation tone.

Cancel Call Forward (\*73) – Disables current call forwarding.

• Selective Call Forwarding (\*63) – Forward calls from a list of up to 12 people to another phone line. All other calls will ring through normally. Enter code again to edit or cancel Selective Call Forwarding. Simply listen to the helpful prompts that will walk you through setting up, adding and removing numbers or turning off this feature.

**Note:** Selective Call Forwarding and Call Forwarding can be available on the same line, but only one can be active at a time.

- Selective Call Rejection (\*60) Screen calls from up to 12 numbers that you specify. Enter code again to edit or cancel Selective Call Rejection. Simply listen to the helpful prompts that will walk you through setting up, adding and removing numbers or turning off this feature.
- Selective Call Acceptance (\*64) Accept calls only from phone numbers that you specify. Simply listen to the helpful prompts that will walk you through setting up, adding and removing numbers or turning off this feature.
- Anonymous Call Rejection (\*77) Automatically block numbers that have disabled their
  Caller ID information. They will hear a message that you are not receiving anonymous calls with
  instructions on how to disable their Caller ID privacy.

Cancel Anonymous Call Rejection (\*87) – Disables anonymous call rejection.

- **Distinctive Alert (\*61)** Assign up to 12 phone numbers a distinctive ring. To set up this feature, dial \*61, then follow the helpful prompts to add or remove numbers.
- Speed Dial (\*74) Store up to eight unique numbers for convenience and speed. Adding a new
  number on speed dial automatically replaces the previously saved number. To remove a speed dial
  number, follow the directions below without entering a phone number.
  - 1. Pick up the line and listen for the dial tone.
  - 2. Dial \*74 and listen for a second dial tone.
  - 3. Enter a one-digit code from two to nine, followed by the local or long-distance number you want to store exactly how you would need to dial it to make the call and then press the # button to store it.
  - 4. Listen for two beeps or a recording to confirm the number is stored and hang up.

**Note:** To dial a saved speed dial number, at the dial tone, press the appropriate one-digit number followed by the # key.

- Two-Digit Speed Dial (\*75) Store up to thirty unique numbers for convenience and speed.
   Adding a new number on two-digit speed dial automatically replaces the previously saved number.
   To remove a speed dial number, follow the directions below without entering a phone number.
  - 1. Pick up the line and listen for the dial tone.
  - 2. Dial \*75 and listen for a second dial tone
  - 3. Enter a two-digit code from twenty to forty-nine, followed by the local or longdistance number you want to store exactly how you would need to dial it to make the call and then press the # button to store it
  - 4. Listen for two beeps or a recording to confirm the number is stored and hang up.

**Note:** To dial a saved speed dial number, at the dial tone, press the appropriate two-digit number followed by the # key.

- Three Way Calling Bridge together two lines in addition to your own so that three separate individuals can speak on a single call.
  - While on a call with one of the individuals you wish to conference with, press the receiver button for one second. You will get a dial tone and the other caller will be put on hold.
  - Dial the number of the third party. When you get an answer, press the receiver button briefly again and all three parties will be connected. If the third party does not answer the phone, press the receiver button two times to cancel. You will still be connected to the first call.
  - 3. When either of the people you called hangs up, you remain connected to the other person. When you hang up, everyone is disconnected.

**Note:** Some phones have a "flash" or "link" button. Use this instead of the receiver button to change lines. While using three-way calling, call waiting is unavailable.

### **Troubleshooting Tips**

Power-cycling a Telephony Modem will often resolve most phone issues. If your Telephony Modem has a battery backup, please remove it before attempting a power cycle.

- 1. Unplug the power from the MTA for one full minute.
- 2. Plug the power back into the MTA and wait for all the lights to become solid.
- 3. Pick up your hand set and check for dial-tone

**Note:** It can take up to 5 minutes for phone service to restore after a power cycle.

- If the Online light is blinking on your modem, press the standby button to take your MTA out of standby mode.
- If the Downstream (DS) or Upstream (US) lights are blinking, see the internet troubleshooting steps located on page 30.
- Unplug the phone line from Line 1 in the back of the MTA and set aside. Plug a non-cordless phone directly into the MTA and test for dial-tone. If there is a dial-tone, plug each of your phones in one at a time to try and find the piece of equipment causing the problem.
- Some equipment such as fax machines, certain cordless phones and caller ID units were designed before digital phone service was available. Please check with the manufacturer to determine if your equipment can be used with a digital phone line.
- Voice Mail can interfere with a fax machine by taking the calls and/or confusing a fax machine into
  thinking there is no dial tone. Plug a phone directly into the line and listen for a staggered dial tone.
  If a staggered dial tone exists you must first check the voice mail on that line and then call Customer
  Service to have the voice mail feature removed.



#### **Call Data Records**

If you are having technical difficulties with an existing feature of your Astound Phone service, it is very helpful to have a call data record ready before calling technical support. Simply write down the date, time and phone number or feature you are attempting to dial as an example to give to our technical support representative. This information will allow us to investigate the error more quickly.



